

- 1 Film Roller
- 2 Fountain Roller
- 3 Dipping Roller with drive
- 4 Ink Cassette
- 5 Adjustment Eccentric
- 6 Adjusting Lever
- 7 Tappet
- 8 Fountain Blade
- 9 Geared Motor
- 10 Potentiometer

