

Golden Rules of Maintenance for :ELANTRIX 95 S / 125 S / 150 S

WARNING! Before handling or using any graphic art material, please read the Material Safety Data Sheet.
Disconnect the Processor from the main power supply. If changing the chemistry please wear glasses, gloves etc.

Section	Task	Comments	Frequency	Time (approx)
Developer	Check bottle levels	For developer fill up and replenisher	Daily	2 min
	Clean transport rollers	Water and sponge	Daily	10 min
	Check the bottle for overflow	Check and empty	Daily	5 min.
	Filter change	If you change the filter, please turn of the processor, drain the filter and open the filter cap.	After about 150 m ²	10 min
	Plate guide	With SATEC 235, after 5 – 8 min. soaking and cleaning with a brush.	With dev. change	35 min
	Main Clean: 1 x with 10% citric acid solution 1 x rinse thoroughly with warm water 1 x with Developer	Water temperature = 30° C. Wash with developer to drain water in the pips	Monthly or with every 2 rd dev. change	120 min
Rinse	Scavenger roller.	Cleaning with sponge and water	Daily	2 min.
	Clean bristle brush / clean spray bar holes	Remove rollers and spray bar clean with warm water = 30° C	Inspect Daily	5 min
	Clean transport rollers	Use anti limestone or developer and warm water	Weekly	10 min
	Thorough Clean,	Use citric acid with every 3 rd dev. change	With dev. change	15 min
Gumming	Moloton roller clean	Use warm water, or change the bottle with gum to bottle with water.	Daily	10 min.
	Check bottle level	Please follow the instruction for gum.	Daily	2 min
	Clean transport rollers	Only with warm water	Weekly	10 min
	Thorough clean, including Gum pipe(s) with warm water	Water temperature = 40° C, change the bottle	Weekly	25 min
Final Drive	Clean / check the wheels are & free from gum deposit	Use warm water to remove gum deposits	Monthly	15 min

Please, observe also the service instructions.

By using cleaners, which are not recommended, you may destroy parts of the processor (guaranty can go out).