



I Despair

Gentlemen,

You need to learn and apply *Large Offset Press techniques/practices* to maintain the roller trains on Duplicator type presses.

I suggest the following –

Roller care, a) use only Water Miscible roller/blanket wash b) final rinse using *lukewarm water* – Not hot and no Ammonia.

Once a month use a Roller Rejuvenator/Deglaze such as *Varn Revitol*.

If the compliant rollers are really glazed remove them smothering them in a Caustic paste such as Bottcher *Feboclean Paste*, leave the rollers overnight then wash paste off with warm water and dry.

Regards, Alois